

ALPA 120 Slim Doors

460 Southport Commerce Blvd.
Spartanburg SC 29306
Phone: 864-574-6004
Fax: 864-574-6005




DOOR INSTALLATION ALPA-120 SLIM




PARTS INCLUDED IN THE KIT


1. TWO DOOR ASSEMBLIES



2. TWO HANDLES



3. FOUR SHEET METAL HINGES AND TWO DOOR STOPS



4. FOUR #8 DRILL SCREWS



5. EIGHT #10 DRILL SCREW



6. TWO PINS



TOOLS NEEDED FOR INSTALLATION

A. ELECTRIC SCREWDRIVER



B. PHILLIPS TIP



C. 5/16" SOCKET WRENCH




D. CROSS SCREWDRIVER




STEP 1:

Remove the front acrylic and its plastic moldings



STEP 2:

Place and screw the 4 sheet metal hinges on the posts using #10 x 3/4 screws



STEP 3:

Remove the lower steel hinge by loosening the screws that hold it



STEP 4:

Place the bushing and the lower steel hinge on the lower sheetmetal hinge



STEP 5:

Put the bushing at the upper steel hinge and insert into the sheetmetal hinge.
Assemble with the lower steel hinge and tighten the steel hinge screws to secure the door.




STEP 6:

Repeat the above steps to install the opposite door



STEP 7:

Take the handle and assemble it by screwing it with the door.
Repeat this step for the opposite door



STEP 8:

Place the door stops using the drill screws at the middle of the upper and lower front



STEP 9:

Adjust the doors by loosening and tightening the steel hinge screws and the magnetic stop screws



YOUTUBE

To see a video of how to install the doors, please check out our youtube video with this QR Code.
<https://youtu.be/WuPqVXEgRCU>



QUESTIONS?

Email service@ojedausa.com or call 864-574-6004



<https://ojedausa.com>
460 Southport Commerce Blvd.
Spartanburg SC 29306
Phone: 864-574-6004
Fax: 864-574-6005